

Quick Reference Guide

To Unlock the Dialer

Enter your unlock code to enable the keyboard after power up or after an alarm has been issued. Default code is "911". Key in: "Unlock" + 9 + 1 + 1 + "Enter". See full instructions for changing the code.

To Record Your Outgoing Message

Press the "Rec" key and speak into the microphone. Fill the entire 12-second message as much as possible.

Storing the Phone Numbers to be Dialed

Press the phone number key you wish to change (Ph 1 to Ph 4), key in the phone number just as you would dial it on your phone and press "Enter". The "Pause" key can be used to insert a 2 second delay if needed. To erase a number press the phone number key followed by "Enter".

To Change the Dialing Mode

Dialing mode 0 dials each number 3 times: Key in "Mode" + 0 + "Enter"

Dialing mode 1 dials each number 1 time: Key in "Mode" + 1 + "Enter"

To Check Your Settings

Press "Check" + "Msg" to review your recorded message. Press "Check" + "Mode" to review the dialing mode. Press "Check" + "Ph (1-4)" to review your stored phone numbers.

To Stop an Alarm Notification

To stop the dialer from dialing the programmed numbers, enter the unlock code. For example, if your unlock code is "1234", key in: 1 + 2 + 3 + 4.

MARCO  **POLO**™
Emergency Phone Dialer

Eureka Technology Partners, LLC
Model MP-AD-01 Made in China
www.eurekaproducts.com

Copyright © 2013 Eureka Technology Partners, LLC ALL RIGHTS RESERVED